

# BUMPER OVERRIDERS

FOR VOLKSWAGEN BUS  
CHAMPAGNE II EDITION

SET OF 4, COMPLETE, PART No. ZVW 151 870

## Kit contains:

4 OVERRIDERS - MOUNTING LOCATION MARKED ON INSIDE OF SHELL:

- "LF" - LEFT FRONT (ZVW 151 871)
- "RF" - RIGHT FRONT (ZVW 151 872)
- "LR" - LEFT REAR (ZVW 151 873)
- "RR" - RIGHT REAR (ZVW 151 874)

4 SPACER BUSHINGS (PLASTIC)

4 LARGE FLAT WASHERS

4 LOCK WASHERS

4 NUTS

8 VINYL STRIPS

## Required but not included in kit:

DRILL, 3/8" DRILL BIT, 5/8" DRILL BIT (MAY BE SUBSTITUTED BY A  
HOLE SAW OR ROUND FILE).

MEASURING TAPE (INCH)

SHARP KNIFE

ALLEN WRENCH 4MM

## INSTALLATION INSTRUCTIONS

- PLEASE READ THE ENTIRE TEXT BEFORE STARTING THE INSTALLATION -

NOTE: 1) ALL MOUNTING HOLE LOCATIONS ARE MEASURED FROM THE BUMPER/  
VEHICLE CENTRE LINE.

- 2) USE OF THE SUPPLIED SPACER BUSHINGS IS REQUIRED ON ALL INSTALLATIONS.
- 3) START WITH REAR.

### REAR

MARK 23" FROM CENTER LEFT & RIGHT  
(BETWEEN TAILLIGHT AND ENGINE COM-  
PARTMENT).

### FRONT

MARK 17" FROM CENTER LEFT & RIGHT

AT THESE LOCATIONS, CUT 1/2" DIAMETER HOLE INTO THE CENTER OF THE RUBBER INSERT. CENTER PUNCH THE METAL STRIP ON THE INSIDE OF IT. DRILL 3/8" DIAMETER HOLE(S). SLIP ON VINYL STRIPS ALONG ENTIRE INSIDE EDGE OF THE OVERRIDER SHELLS. PLACE PLASTIC SPACERS, THEN LARGE FLAT WASHERS ONTO THE MOUNTING BOLTS.

CONTINUE ON REAR:

INSTALL OVERRIDERS AS MARKED:

"LR" ON LEFT REAR AND "RR" ON RIGHT REAR. TIGHTEN SECURELY WITH LOCK WASHER AND NUT.

TO INSTALL FRONT OVERRIDERS IT IS NECESSARY TO REMOVE FRONT BUMPER: LOOSEN FASTENERS AT ENDS OF RUBBER - INSERTS WITH 4 MM ALLEN WRENCH AND DETACH RUBBER INSERT. REMOVE 4 BUMPER MOUNTING BOLTS AND DETACH BUMPER FACEBAR. REINSTALL RUBBER INSERT ONTO BUMPER FACEBAR. INSTALL OVERRIDERS "LF" ON LEFT AND "RF" ON RIGHT OF BUMPER. CHECK RUBBER INSERT FOR PROPER ALIGNMENT BEFORE TIGHTENING OVERRIDERS WITH LOCK WASHERS AND NUTS.

ENLARGE THE TWO (2) 3/8" DIAMETER HOLES IN SHEET METAL OF APRON TO APPROXIMATELY 5/8" DIAMETER - REQUIRED FOR CLEARANCE FOR THE PROTRUDING OVERRIDER MOUNTING BOLTS AND NUTS.

REINSTALL BUMPER ASSEMBLY ON VEHICLE AND FASTEN RUBBER INSERT.